

## PLATINUM SERIES

## Extensive Coverage

✓	ENGINE	Engine block, cylinder heads, crankshaft and main bearings, crankshaft gears, connection rods and bearings, camshafts and bearings, camshaft gears, push rods, pistons, rings and pins, intake and exhaust valves, valve springs and retainers, valve covers, guides, lifters, rocker arms, shafts and pivots, timing chains, oil pump and shaft, dip stick and tube, timing gears, guides, tensioners, seals, harmonic balancer, oil pan, timing chain cover, intake and exhaust manifolds, valve covers and engine mounts.
✓	TRANSMISSIONS	Automatic Transmission: All internally lubricated parts including housing, torque converter, valve body, gear sets, main and intermediate shafts, vacuum modulator, and oil pump. Standard: All internally lubricated parts including housing, main and intermediate shafts, gear sets, synchronizer rings, shifter fork and bearings.
✓	DIFFERENTIAL / AUXILIARY DIFFERENTIAL	a) Front Wheel Drive Vehicles (transaxle): All internally lubricated parts including housing, main shafts, crown and pinion, pinion gears, and bearings. b) Rear Wheel Drive Vehicles: All internally lubricated parts including housing, carrier gear and case, drive pinion and pinion gear, ring gear, differential cover, differential mounts, and bearings.
✓	AUXILIARY TRANSFER CASE (AWD/4WD)	All internally lubricated parts including case, gears and sprockets, and chains. (Front and rear) locking hubs, drive shafts, centre support bearings, universal joints, constant velocity joints, axle bearings, and four wheel drive actuator.
✓	SEALS AND GASKETS	All seals and gaskets used to contain fluids or lubricants for parts necessary to assemble or replace a covered component, every repair includes the replacement of coolants, refrigerants, transmission fluid and filter, engine oil and filter, hydraulic lubricants when required as a result of a failure of a covered component.
✓	TURBOCHARGER / SUPERCHARGER	All internal parts including housing, wastegate controller, intercooler and hard lines. All internal parts including housing, compressor, clutch and pulley, bypass valve, intercooler and ducting.
✓	FRONT SUSPENSION	Upper and lower ball joints, upper and lower control arms and their shafts and bushings, steering knuckles, and kingpins and their bushings.
✓	REAR SUSPENSION	Torsion bars and mounts or bushings, stabilizer bar, links and bushings, spindle support, wheel bearings, variable dampening suspension compressor, control module, actuator, solenoid, height sensor, and mode selector switch.
✓	HEATING AND COOLING SYSTEMS	Engine cooling fan and motor, fan clutch, belt tensioner, heating core, thermostat, hot water valve and water pump
✓	FUEL INJECTION	Pressure regulators, fuel injector lines, fuel injectors, injection/distribution and fuel pumps.
✓	FUEL DELIVERY / SYSTEM	Vacuum pump, fuel tank, fuel tank sending unit and metal fuel delivery lines.
✓	BODY HARDWARE	Fuel door release cable, hood release cable, and trunk release cable.
✓	ELECTRICAL SYSTEM	Starter motor and solenoid, alternator, voltage regulator, electronic ignition module (excluding computer system), windshield wiper motors, washer pump motors, heater motors and fan, horn assembly, starter ring gear and starter drive, engine wiring harness, transmission wiring harness, computerized timing control unit, powertrain control module, crank angle sensor, cam sensor, knock sensor, ignition switch lock cylinder, front and rear window wiper motor and manual heater/A.C. control head.
✓	ENHANCED ELECTRONIC HIGH TECH	Electronic anti-lock brake system (ABS), traction control system (TCS) including electronic brake control module, exciter rings, pump motor/hydraulic unit, relays, accumulators, pressure modulator valve assembly, electronic temperature control module, electronic ignition computer control modules, fuel injection computer control modules, cruise control servo, transducer and cable, digital dash instrumentation including speedometer, tachometer, odometer, fuel, oil, temperature, compass readout, thermometer readout and voltage displays, keyless entry system, door control module and lock actuators, power door lock actuator motor and switches, power window motors, power seat motors, power antenna, electronic trunk release actuator, exterior mirrors, sunroof motor, convertible top motors, hidden headlight door motors and electronic automatic load levelling compressor motor, ignition coil packs, coil pack housing, oxygen sensor, electronic combination entry system, power seat switch, rear defogger switch and power door lock switch.
✓	STEERING SYSTEMS	Rack and pinion, power steering pump and pulley, fluid reservoir, hydraulic lines, steering gear, main and intermediate shafts, pitman arms, idler arms, centre link, steering knuckles (spindles), kingpins and bushings, cooler and lines, all internal parts contained within the steering box, power steering hoses, tie rod ends and drag link, steering dampener, upper and lower steering column shafts and couplings, internal tilt wheel mechanism, steering box, rear wheel steering, rear steering shaft and couplings, power cylinder and pump, electronic rear wheel steering, power cylinder and pump, electronic control unit/solenoid, phase control unit, stepper motor and control valve.
✓	BRAKING SYSTEMS	Master cylinder, assist booster, proportioning valves, wheel cylinders, backing plates and return springs, front and rear calipers, hard lines and fittings, flex lines, brake linkages and cables, hydro boost, seals and gaskets. The following ABS parts are also covered: electronic control processor, wheel speed sensors, and valve/isolation dump valve.
✓	AIR CONDITIONING	Compressor, clutch assembly and pulley, evaporator, accumulator, expansion valve, orifice tube, receiver-dryer, idler pulley and bearings, condenser, refrigerant lines, belt tensioner, high/low compressor cut-off switch, expansion valve, and pressure cycling switch. The following parts are also covered if they are required in connection with the repair of a covered part listed above: oil and refrigerant.
✓	NAVIGATION SYSTEM DVD	It covers manufacturer original installed components only.
✓	ROADSIDE ASSISTANCE	We will reimburse you up to \$50 per occurrence to an aggregate maximum of \$250 including all applicable taxes for the following events when related to an approved claim for services: a) Winching services for your vehicle stuck in snow, mud or off the road b) Battery boosting service to start your vehicle. c) Emergency fuel delivery service for your vehicle if it has run out of fuel (up to ten litres). d) Flat tire repair or installation of the spare. e) Vehicle entry service (locksmith service) for your vehicle should the keys be lost or locked in your vehicle.
✓	TOWING	We will reimburse you up to \$50 per occurrence to an aggregate maximum of \$200, including all applicable taxes, for towing expenses incurred due to a mechanical breakdown.
✓	CAR RENTAL / TRIP INTERRUPTION	a) Car Rental: We will reimburse you for car rental expenses incurred due to a mechanical breakdown. Benefits will be payable if the labour time allocated by a current recognized professional labour guide exceeds eight hours, requiring that your vehicle be kept in a repair facility overnight. Reimbursement is up to \$40 per day to a maximum of \$200 for the term of this contract. b) Trip Interruption: We will reimburse you for lodging, meals, bus or taxi expenses incurred due to a mechanical breakdown. Benefits will be payable if you are more than 300 kilometres away from the registered residence (one way) and labour time allocated by a current recognized professional labour guide exceeds eight hours, requiring that your vehicle be kept in a repair facility overnight. Reimbursement is up to \$50 per day to a maximum of \$200 for the term of this contract.
✓	WEAR AND TEAR \$5000 PER CLAIM DIAGNOSTICS WHEEL BEARINGS SHOP FLUIDS	\$5000 per claim up to the retail value of the vehicle. Additional Coverage for Platinum Products. Refer to warranty contract for full details. Diagnostic coverage begins after the first hour. Every repair includes the replacement of coolants, refrigerants, transmission fluid and filter, engine oil and filter, hydraulic fluid and lubricants



Coverage	Gold	Silver	Bronze	Top Up
Engine	✓	✓	✓	Covered by manufacturer
Diesel Engine	✓	✓	✓	Covered by manufacturer
Transmissions	✓	✓	✓	Covered by manufacturer
Auxiliary Transfer Case (AWD/4WD)	✓	✓	✓	Covered by manufacturer
Differential / Auxiliary Differential	✓	✓	✓	Covered by manufacturer
Roadside Assistance / Towing	✓	✓	✓	✓
Seals and Gaskets	✓	✓	Optional	✓
Turbo / Supercharger	✓	✓	Optional	✓
Air Conditioning	✓	Optional	Optional	✓
Electrical System	✓	Optional		✓
Front Suspension	✓			✓
Steering Systems	✓			✓
Braking Systems	✓			✓
Fuel Injection	✓			✓
Electronic High Tech	Optional	Optional		✓
Car Rental	Optional	Optional	Optional	✓

This brochure is not a contract, it is an outline and the content may change without notice.

All benefits described are subject to the terms and conditions of the warranty contract. Refer to the warranty contract for full details.

## AVAILABLE OPTIONS

**Seals and Gaskets** ■ (Included in Gold and Silver)

**Air Conditioning** ■ (Included in Gold)

**Electrical System** ■ (Included in Gold)

**Electronic High Tech** ■ ■

Electronic anti-lock brake system (ABS), traction control system (TCS) including: electronic brake control module, exciter rings, pump motor/hydraulic unit, relays, accumulators, pressure modulator, valve assembly, electronic temperature control module, electronic ignition computer control modules, fuel injection computer control modules, cruise control servo, transducer and cable, digital dash instrumentation including speedometer, tachometer, odometer, fuel, oil temperature, compass readout, thermometer, readout and voltage displays, keyless entry system, door control module, lock actuators, power door lock actuator motor and switches, power window motors, power seat motors, power antenna, electronic trunk release actuator, exterior mirror motors, sunroof motor, convertible top motors, hidden headlight door motors, and electronic automatic load leveling compressor motor.

**Car Rental** ■ ■ ■

You will be reimbursed for a vehicle rental if a covered component fails. This reimbursement will be up to \$40 per day to a maximum of \$200

**Zero Deductible** ■ ■ ■ ■ ■

**\$5,000 Per Claim Liability** ■ ■ ■ (Gold and Silver only)

**Top Up Powertrain Plus** ■ (Includes all powertrain components listed)

## Fully Insured

**IA** **INDUSTRIAL ALLIANCE**  
INSURANCE AND FINANCIAL SERVICES INC.

We are a proud member of the UCDA



**PEOPLES CHOICE**  
**WARRANTY**  
*Protection That Pays*

**Bronze** **Silver** **Gold**

**PLATINUM SERIES**

**North American Toll Free**  
**1-888-284-2356**

[www.peopleschoicewarranty.com](http://www.peopleschoicewarranty.com)

P: (519) 485-2616 F: (519) 425-2654  
28 King St. E. Unit B, Ingersoll  
Ontario Canada N5C 3L8

### PLANS TO FIT YOUR NEEDS

**Engine:** All internally lubricated parts including engine block, cylinder heads, timing chains, crankshaft, main bearings, connecting rods and bearings, push rods, pistons, piston rings and pins, intake, exhaust valves and springs, valve guides, lifters, and oil pump.

**Transmissions:** (Automatic and Standard) All internally lubricated parts including torque converter, valve body, gear sets, main and intermediate shafts, synchronizer rings, shifter forks, bearings and housing.

**Auxiliary Transfer Case (AWD/4WD):** All internally lubricated parts including gears, shifter forks, snap rings, bearings and housing.

**Differential/Auxiliary Differential:** All internal parts including ring gear, pinion gear, side gears, and differential bearings.

**Roadside Assistance/Towing:** On Roadside Assistance you will be reimbursed up to \$50 per occurrence to a total amount of \$250 for the following events: winching, battery boosting, emergency fuel delivery, flat tire and locksmith service. Maximum towing reimbursement is \$200.

**Seals and Gaskets:** All seals and gaskets used to contain fluids within the engine, transmission, auxiliary transfer case, differential and auxiliary differential.

**Turbo/Supercharger:** All internal parts including housing, wastegate controller, turbine wheel and intercooler.

**Air Conditioning:** Compressor, evaporator, accumulator, receiver-drier, expansion valve, orifice tube, and clutch assembly.

**Electrical System:** Alternator, starter motor and solenoid, heater motors, wiper motors, washer pump motors, voltage regulator, electronic ignition module, distributor, horn, and water pump.

**Front Suspension:** Ball joints (upper and lower) control arms (including their shafts and bushings), steering knuckles, kingpins, and bushings.

**Steering Systems:** Rack and pinion, power steering pump and pulley, pitman arms, idler arms, centre link, steering knuckles, kingpins and bushings, hydraulic lines, fluid reservoir, cooler, and lines.

**Braking Systems:** Master cylinder, booster, front and rear callipers, wheel cylinders, brake linkages and cables, backing plates, return springs, proportioning valves, flex lines hard lines, and fittings.

**Fuel Injection:** (Gasoline and diesel) Fuel pumps, fuel injectors, pressure regulators, and fuel injector lines.